



Suggest to apply screw glue after assembly.

BS-2502
(From car kit)

BS-2502
(From car kit)

BE-3625
(From car kit)

"Turns clockwise"

BE-3625
(From car kit)

BE-3625
(From car kit)

BE-3625
(From car kit)

