



Instruction for GL Tweak Calibrator


Date: July 2021















Try to align marking with zero based on the below procedure 6.2.

Calibrating procedure

Check the chassis left / right balance. Install wheels in same diameter and place on flat floor. Lift the front up to see left and right wheels apart from the floor, you will see 2 situation below.



6.2 One of the wheel apart the floor first. For example, if the **left** wheel apart first, adjust the **right** side damper (above the motor) in adding the shim (SM6) until both wheels apart the floor like 6.1. If the right wheel rise up first, do the same on other side.



Lift it up