

Item No:	Items Name:	Value:	Item No:	Items Name:	Value:
1	Running Mode	1- Forward/Brake 2- Forward/Brake/Reverse 3- Forward/Reverse	13	Brake Force	1- 0% 2- 12.5% 3- 25% 4- 37.5% 5- 50% 6- 62.5% 7- 75% 8- 87.5% 9- 100%
2	Low Voltage Cutoff	0- Disable 1- Auto 2- 3.0V 3- 3.1V 4- 3.2V ... 83 - 11.1V	14	I-Brake Response	1~20 = brake 1~20
3	ESC Overheat Protection	0- 95 degree 1- 105 degree 2- 130 degree 3- Disable	15	Brake Rate	1~20 = brake 1~20
4	Motor Rotation	1- Normal 2- Reverse	16	Brake Freq	1- 1k 2- 2k 3- 4k 4- 8k 5- 16k
5	Race Mode	1- Modify 2- Stock	17	Boost Timing	0~64= 0~64 timing
6	Dead Band	1 - 4% 2- 5% 3- 6% ... 12- 15%	18	Boost Trigger Level	1~50 = level 1~50
7	IP Limiter	1~30 = punch 1~30	19	Boost Trigger Rate	1~10 = rate 1~10
8	Throttle Rate	1~30 = punch 1~30	20	Turbo Timing	0~64 = 0~64 turbo
9	Drive Freq	1- 1k 2- 2k 3- 4k 4- 8k 5- 16k	21	Turbo Delay	0 - instant 1- 0.05s 2- 0.1s 3- 0.15s ... 15 = 1s
10	RPM Lock	0- 1% 2- 2% 3- 3% ... 99 - 100%	22	Turbo On Rate	1~10 = rate 1~10
11	Initial Brake	1=1% 2=2% ... 20=20%	23	Turbo Off Rate	0- instant 1~10 = rate 1~10
12	Drag Brake	0~99= 0~99%			